

<b>PROCESSING PRECI-BALL AVK</b>
----------------------------------

1. Wax up the post-copings. Solder the **1203 C** males to the post-copings (see INFO 048, items 1-8).
2. Screw the **1207 A** female into the **694 AKS2** retention part (always using the **IMP-XS-042** screw-driver) and place the female on the male.
3. Position the **RA 0055** large space maintainer.
4. Polymerize the female into the prosthesis.
5. Adjust the retention after finishing the prosthesis (see INFO 053).