

## PROCESSING PERMA-RET

1. Determine the exact position for the **1602** PERMA-RET wire.
2. Place the **1606** burr into a handpiece. Drill an approximately 3 mm deep hole in the tooth.
3. Place the retention wire in the **1604** wire holder.
4. Screw the wire into the opening.
5. Cut the wire to the required length (approximately 4 mm) with pliers or a separating disc.
6. Bend or squeeze the end of the wire. It will then offer retention for acrylic resin.